


Using the Test Probe

- 1) Unseat the Test Probe from its holder and uncoil wire
- 2) Connect Butt Set to binding posts of Test Probe Holder



- 3) With open end of probe facing downwards, align the probe over an IDC rocker paddle



- 4) Press the probe down until it seats over IDC rocker paddle. A noticeable click will be felt



IDC Rocker Wire Insertion

1. Installation is accomplished using standard Contacts (IDC), are achieved using gel sealed rockers.

2. Lift the rocker to the full up position. **DO NOT** strip wires. Hold the wire pair to be terminated between thumb and index finger. Insert wires into wire guides simultaneously until they bottom-out. While holding wires in position, terminate rocker by lowering to the full DOWN position. (See Pictures).

3. Terminate any additional wire pairs as required following the above steps

