
P/N 92233702 • Rev E • ECN 13-282 • 11/11/2013

Warranty: If this unit fails during the warranty period, contact til customer service to authorize return. Unit may be returned prepaid.



141 Rodeo Drive Edgewood, NY 11717 Toll Free 888.844.4720 www.tiinetworktechnologies.com

Model 65-10, 65T-10 10 Pair Terminal Block



Installation Note

Description

 The 65-10 and 65T-10, 10 Pair Terminal Blocks are used to join Twisted Pair Telecom Cables. The 65-10 and 65T-10 consist of two rows of contacts, the back row for permanent connection, the front row for jumper wires. Each wire pair provides a permanent link between the equipment and jumper side, allowing 'listen' access via the test probe ports.





Figure 1

Features

Installation

- Installation is accomplished using standard technician tools. The Insulation Displacement Contacts (IDC), are achieved using gel sealed rockers.
- Lift the rocker to the full up position. DO NOT strip wires. Hold the wire pair to be terminated between thumb and index finger. Insert wires into wire guides simultaneously until they bottom-out. While holding wires in position, terminate rocker by lowering to the full DOWN position. Figure 2.
- 3. Terminate any additional wire pairs as required following the above steps.
- 4. To keep wire pairs organized, route them through the molded wire looms as shown in Figure 2.



 Before inserting Test Probe match wire colors to Rocker, green wire Tip, red wire Ring